



## MF-1 Fitting Instructions

1. Remove the toilet pan - This can be done by a competent DIY enthusiast or your local plumber.
2. Remove the toilet pan connector from the back of your toilet (the toilet pan connector is white in colour with a back rubber ring).
3. Remove the back rubber from the existing pan connector or your new pan connector.
4. Remove the **MF-1** from its packaging and push the **MF-1** onto the pan connector. On the lid you will find the word "top" - this is to be fitted to the pan connector so that the lid opens in an upwards fashion to allow full discharge when the toilet is flushed. Always ensure that the lid opens upwards when using a horizontal pan connector.
5. When fitting to a vertical pan connector, ensure that the lid will open working with the flow of any bends.
6. Re-fit the toilet as you would normally, the **MF-1** will seal all pipes just like a standard non-protected pan connector.

You are now fully protected and the doorway from the sewer to your toilet is closed!

